



CUT-OUT TEMPLATE

← Position of clamp fixings x 4

250mm (9 7/8") DIAMETER

How to use this template

- 1) Remove the Protective backing from the "low tack" adhesive tape on rear of this template.
- 2) Align centre lines (optional)
- 3) The outside profile is an accurate indication of the speaker box hole required.
- 4) Draw around the profile, remove template and cut hole.
- 5) The template can be repositioned a number of times if required

